



GMS (220 Conversion Kit) Instructions

IMPORTANT NOTE: the GMS 220v conversion kit is for use on your 220v plug for your electric stove or electric dryer. This will not work with gas appliances.

Step 1: Pull out stove or dryer and unplug the 220v plug from the outlet.

Step 2: Find the correct adapter in the GMS bag and plug into the 220 outlet. We have 4 different options available.



Step 3 (IF NEEDED): Plug the adapter cord into the 25' black extension cord provided in the GMS Kit. Twist to ensure that the plug is in correctly and is tight.



Step 4: Plug the adapter or black extension cord from Step 3 into the blue GMS box. Twist to ensure that the plug is in correctly and is tight. If everything is plugged in correctly, a small green light on each of the 4 outlets on the blue GMS Box will light up.



Step 5: Plug the cords provided with the heater into the outlets on the GMS box. Whether you are plugging in 3 or 4 cords, do not double up on any one outlet. Use 3 different outlets or all 4 outlets on the GMS box.



Step 6: Plug cords into the heater. If everything is plugged in correctly, the ends of all the cords will light up along with the orange indicator lights on the heater.

